

# 富知源烫钻机配件图册

## FZY RHINESTONE MACHINE SPARE PARTS LIST

序号	零件名称	NAME	PARTS	REMARK
1	超声波	ULTRASONIC	PARTS NO.001	
2	气缸 (横)	CYLINDER 1	PARTS NO.002	
3	气缸 (竖)	CYLINDER 2	PARTS NO.003	
4	塑料锥齿轮	GEAR	PARTS NO.004	
5	电脑板	HEAD CARD	PARTS NO.005	MIXED MACHINE混合机系列
6	电机	MOTOR	PARTS NO.006	
7	传感器	AIR SENSOR	PARTS NO.007	
8	高温垫	STONE FIX CUSHION	PARTS NO.008	Roughly 0.3X1M
9	两通电磁阀	SOLENOID VALVE/2	PARTS NO.009	
10	三通电磁阀	SOLENOID VALVE/3	PARTS NO.010	
11	真空发生器	VACUUM GENERATORS	PARTS NO.011	
12	五通电磁阀	SOLENOID VALVE/5	PARTS NO.012	
13	缓冲件	RUBBER STOPPER	PARTS NO.013	
14	24V开关电源	24V SMPS	PARTS NO.014	
15	激光灯	LASER LIGHT	PARTS NO.015	
16	双向节流阀	BOUDLE WAY VALVE	PARTS NO.016	
17	滤芯	FILTER	PARTS NO.017	
18.1	盘	DISK	PARTS NO.018	SS12、Ss16
18.2	盘	DISK	PARTS NO.018	SS20、Ss30
19	吸嘴	NOZZLE	PARTS NO.019	
20	小过滤器	STRAINER	PARTS NO.020	
21	单向节流阀	SINGLE WAY VALVE	PARTS NO.021	
22	塑料盖	COVER	PARTS NO.022	
23	润滑白油	OIL	PARTS NO.023	
24	摆动关节轴承	KNUCKLE BEARING	PARTS NO.024	
25	限位摆动板	LIMIT ROD	PARTS NO.025	
26	摆动轴	LIMIT SHAFT	PARTS NO.026	
27	5200轴承	5200 BEARING	PARTS NO.027	旋转rotary
28	6001轴承	6001 BEARING	PARTS NO.028	摆动waver
29	旋转轴	ROTARY SHAFT	PARTS NO.029	
30	吸嘴连接件	NOZZLE CONNECT	PARTS NO.030	
31	电机安装板	MOTOR SUPPORT	PARTS NO.031	多头multi-head
32	滑台汽缸	SHAFT CYLINDER	PARTS NO.032	
33	毛刷	BRUSH	PARTS NO.033	
34	微动开关	SWITCH	PARTS NO.034	
35	5.5X7呆板手	5.5X7 SPANNER	PARTS NO.035	
36	8X10呆板手	8X10 SPANNER	PARTS NO.036	
37	10X12呆板手	10X12 SPANNER	PARTS NO.037	
38	水果盘	STONE PLATE	PARTS NO.038	
39	脚踏开关	FOOT SWITCH	PARTS NO.039	
40.1	电位器2K	POTENTIONMETER 2K	PARTS NO.040	
40.2	电位器22K	POTENTIONMETER 22K	PARTS NO.040	
41	电位器 (传感器)	POTENTIONMETER SESOR	PARTS NO.041	
42	传感器连接线	SENONR CABLE	PARTS NO.042	
43	激光灯安装座	LASER LIGHT SUPPORT	PARTS NO.043	
44	二分三通	1/2" THREE WAY CONNECT	PARTS NO.044	
45.1	三变二补芯	1/3" TO 1/2' CORE	PARTS NO.045	
45.2	二变一补芯	1/2" TO 1" CORE	PARTS NO.045	
46	二分插8接头	1/2" TO 8MM CONNECT	PARTS NO.046	
47	二分堵头	1/2" STOPER	PARTS NO.047	
48	二分插4接头	1/2" TO 4MM CONNECT	PARTS NO.048	
49	二分插8弯接	1/2" TO 8MM BENT CONNECT	PARTS NO.049	
50	二分插8三通	1/2" TO 8MM 3 WAY CONNECT	PARTS NO.050	
51	二分插8内螺纹三通	1/2" TO 8MM 3 WAY CONNECT 1	PARTS NO.051	
52.1	直径8三通	8MM 3 WAY CONNECT	PARTS NO.052	
52.2	直径6三通	6MM 3 WAY CONNECT	PARTS NO.052	
53	电机安装板	MOTOR SUPPORT	PARTS NO.053	
54	三位底板	SUPPORT FOR 3 VALVE	PARTS NO.054	
55	档圈配件	RING	PARTS NO.055	
56	限位支架	LIMIT SUPPORT	PARTS NO.056	
57	数码电脑板	LCD BOARD	PARTS NO.057	SINGLE HEAD FZY-S系列
58	液晶电脑板	LED BOARD	PARTS NO.058	SINGLE HEAD FZY-Y系列
59	三分滑阀	MAIN AIR SWITCH	PARTS NO.059	
60	二位底板	SUPPORT FOR 2 VALVE	PARTS NO.060	
61	二分过滤调压阀	1/2" ADJUST VALVE	PARTS NO.061	
62	三分过滤调压阀	1/3" ADJUST VALVE	PARTS NO.062	
63	M5插4快接	5MM TO 1/4" CONNECT	PARTS NO.063	
64	M5插4弯接	5MM TO 1/4" BENT CONNECT	PARTS NO.064	
65	船型开关	MAIN SWITCH	PARTS NO.065	SINGLE HEAD



PARTS NO.001



PARTS NO.002



PARTS NO.003



PARTS NO.004



PARTS NO.005



PARTS NO.006



PARTS NO.007



PARTS NO.008



PARTS NO.009




PARTS NO.010



PARTS NO.011



PARTS NO.012



PARTS NO.013



PARTS NO.014




PARTS NO.015



PARTS NO.016



PARTS NO.017



PARTS NO.018



PARTS NO.019-1



PARTS NO.019-2



PARTS NO.020



PARTS NO.021



PARTS NO.022



PARTS NO.023



PARTS NO.024



PARTS NO.025



PARTS NO.026



PARTS NO.027



PARTS NO.028



PARTS NO.029



PARTS NO.030



PARTS NO.031



PARTS NO.032



PARTS NO.033



PARTS NO.034



PARTS NO.035



PARTS NO.036




PARTS NO.037



PARTS NO.038



PARTS NO.039



PARTS NO.040



PARTS NO.041



PARTS NO.042



PARTS NO.043



PARTS NO.044



PARTS NO.045



PARTS NO.046



PARTS NO.047



PARTS NO.048



PARTS NO.049



PARTS NO.050



PARTS NO.051



PARTS NO.052



PARTS NO.053



PARTS NO.054



PARTS NO.055



PARTS NO.056



PARTS NO.057



PARTS NO.058



PARTS NO.059



PARTS NO.060



PARTS NO.061



PARTS NO.062



PARTS NO.063



PARTS NO.064



PARTS NO.065